

## PROCEDURE FOR INCLEMENT WEATHER CONDITIONS

IF THE WEATHER IS TOO COLD OR TOO RAINY TO DO ANALYSIS DIRECTLY AT THE CREEK SITE, PLEASE MAKE THE FOLLOWING MODIFICATIONS TO THE PROCEDURES:

1. THE ONLY MEASUREMENTS THAT ABSOLUTELY NEED TO BE MEASURED AT THE SITE ARE THE DISSOLVED OXYGEN, TEMPERATURE AND PRESSURE (ALL TAKEN WITH THE DISSOLVED OXYGEN METER).
2. THE REMAINDER OF THE MEASUREMENTS CAN BE MADE IN A CAR OR AT ONE'S HOME.
3. IF THE WEATHER IS INCLEMENT:
  - DETERMINE THE DO, TEMP AND PRESSURE MEASUREMENTS AT THE SITE AS USUAL.
  - THE GREEN BOX CONTAINS A LARGE 1 LITER BOTTLE. USE A SAMPLING DEVICE TO RINSE IT THREE TIMES WITH CREEK WATER THEN COLLECT WATER AS USUAL FILLING THE 1 LITER BOTTLE COMPLETELY.
  - THIS 1 LITER OF WATER SHOULD BE SUFFICIENT TO PERFORM ALL OF THE TESTS EXCEPT:
    - PERFORM ONLY ONE TURBIDITY MEASUREMENT